



Icom America, Inc.
2380 116th Ave NE
Bellevue, WA 98004
425.454.7619

Addendum

10/04/07

FR3000/FR4000 Remote Control Manual

Procedure Modification

Procedures in the manual currently describe entering a password and then waiting for an acknowledge response from the repeater before entering the command. For example:

1. Enter the programmed password from the transceiver.

Code: *0001#

- Verify the repeater replies "System Password OKACK (1111)."

To make the procedures work properly, the password and command must be entered on the same line, without waiting for an acknowledge response from the repeater. All commands must be preceded by the password.

For example:

1. Enter the programmed password *and* command from the transceiver.

Code: *0001#0003#

The asterisk (*) tells the repeater to listen for the command; the # separates each instruction.

Affected Parts of the Manual

All procedures starting on page 5 through page 14.