


8-3. TM-531A/531E BLOCK DIAGRAM

downloaded by
Amateur Radio Directory
www.hamdirectory.info



Note: _____

SITIES.


⑥ Microphone connector

downloaded by

Amateur Radio Directory

www.hamdirectory.info

Attach the supplied microphone to this connector. The pin out of the connector is described in the accompanying illustration.




downloaded by

Amateur Radio Directory

www.hamdirectory.info


TM 531 ①



	R7	R8	R9	R10	R13	R14	R18	R43	R60	R61	R100	R101	C19	Q3	Q5	L3	D2	Q1
TM-531A	—	—	—	—	—	—	—	—	3.9k	2.2k	—	—	—	—	—	—	—	—
TM-531E	—	—	—	—	—	—	—	—	10k	0	—	—	—	—	—	—	—	—

TM531②

Downloaded by
Amateur Radio Directory
www.hamdirectory.info




50	R61	R100	R101	C19	Q3	Q5	L3	D2	Q17	IC1
9k	2.2k	○	○	—	—	—	—	○	○	○
3k	0	○	○	—	—	—	—	—	—	—


○ USED
— NOT USED


8-3. TM-531A/531E BLOCK DIAGRAM

TM531 (3)



CK DIAGRAM







A/2


	R7	R8	R9	R10	R13	R14	R18	R43	R60	R61	R100	R101	C19	Q3	Q5	L3	D2	Q17	IC1
TM-531A	—	—	—	—	—	—	—	—	3.9k	2.2k	—	—	—	—	—	—	—	—	—
TM-531C	—	—	—	—	—	—	—	—	10k	0	—	—	—	—	—	—	—	—	—

TM 531 (4)



	R8	R14	R5
J (0000)	2.2k	—	RA77
TM-531A/531C	0	—	—

Submitted by
Amateur Radio Directory
www.amateurradio.info



(TOP)