







PCBX-0619R6 BOTTOM LAYER
MAGNUM S9 MASTER BOARD




PCBX-0619R6 BOTTOM LAYER
MAGNUM S9 MASTER BOARD




PCBX-0619R6 TOP LAYER
MAGNUM S9 MASTER BOARD




PCBX-9709R1
TOP LAYER
MIC SOCKET BOARD



MAGNUM S9
VSWR CONTROL BOARD




MAGNUM S9
VSWR CONTROL BOARD




PCBX-0638
TOP LAYER

MAGNUM S9
VSWR CONTROL BOARD

PCBX-0638
BOTTOM LAYER




MAGNUM S9
VSWR CONTROL BOARD




PCBX-0637R1 TOP LAYER
MAGNUM S9 COUNTER DISPLAY BOARD


PCBX-0637R1-061007




LED303




LED302




LED301





PCBX-0637R1 BOTTOM LAYER
MAGNUM S9 COUNTER DISPLAY BOARD



PCBX-0636R1 TOP LAYER


MAGNUM S9 CHANNEL SWITCH BOARD


PCBX-0636R1-061007


J202

J201


SW201









PCBX-0636R1 BOTTOM LAYER
MAGNUM S9 CHANNEL SWITCH BOARD




PCBX-0635R3 BOTTOM LAYER
MAGNUM S9 FREQ.COUNTER CPU BOARD




PCBX-0635R3 TOP LAYER
MAGNUM S9 FREQ.COUNTER CPU BOARD



PCBX-0635R3 TOP LAYER
MAGNUM S9 FREQ.COUNTER CPU BOARD



PCBX-0635R3 BOTTOM LAYER
MAGNUM S9 FREQ.COUNTER CPU BOARD



PCBX-0619R6 TOP LAYER
MAGNUM S9 MASTER BOARD

